

[www.Rockman.fr](http://www.Rockman.fr)

A - Buy



1 Hammond 1590BB : 119 x 94 x 30  
(Digikey ref: HM152-ND)



3 Mono 1/4" jacks  
This is the original Switchcraft SC-280 jack used by  
SR&D for the Triple Footswitch  
(Mouser ref: 502-280)



3 Carling Footswitch SW 110 P  
(Digikey ref: 432-1209-ND)



20 ft of basic 2 wires  
electric cable

Examples only: any equivalent item  
can be used

B - Drill

*Rear view*



The diameter of the holes must fit the diameter of the cable.  
Strain relieves are recommended.

*Top view*



12.7mm (.5 in)

## C - Solder

### Tips:

- Solder the switches first, then cut the three pieces of cable at the same length.
- Strain relieves are recommended to protect the cables at the box's holes level.
- Don't forget to thread the cable in the jacks' handle before soldering them!
- Lock the handles on the jacks, bolt the box: you're done!

